

**27. Vessel to be ready to work cargo before berthing**

The Master —

- (a) must prepare the vessel's cargo handling equipment including the opening or removal of hatches and hatch beams;
- (b) must have the vessel ready to work cargo before it comes to its Berth; and
- (c) is responsible for replacing hatches and beams.