

26. Conditions where vessel lying outside another vessel

- (1) Where a vessel is lying outside another vessel berthed alongside a wharf —
 - (a) a passenger must not embark onto or disembark from and cargo or ballast must not be loaded onto, or unloaded from, the outside vessel over or across the inside vessel without the permission of the Marine Manager; and
 - (b) the Master of the inside vessel, if so directed by the Marine Manager, must allow passengers from the outside vessel to embark and disembark and cargo and ballast to be loaded or unloaded over and across his or her vessel.
- (2) A person who contravenes sub-bylaw (1)(a) and a Master who contravenes sub-bylaw (1)(b) commits an offence.